

User's Guide



ADI-8 DS Mk III


A true industry standard

SyncAlign™

SyncCheck™

SteadyClock™

Hi-Precision 24 Bit / 192 kHz
Reference Low Latency Conversion
8-Channel Analog <> AES / ADAT Interface
24 Bit / 192 kHz Digital Audio
ADAT <> AES Format Converter

 **adat®** AES-3

24 Bit Interface

▶	Important Safety Instructions	4
▶	General	
1	Introduction	6
2	Package Contents	6
3	Brief Description and Characteristics.....	6
4	First Usage – Quick Start	
4.1	Controls - Connectors - Displays	7
4.2	Quick Start Operation.....	8
5	Accessories	9
6	Warranty.....	10
7	Appendix	10
▶	Usage and Operation	
8	Front Panel Controls	
8.1	A/D Reference.....	14
8.2	A/D State - Meters.....	14
8.3	A/D Output	14
8.4	Patch Mode	14
8.5	Clock Section	15
8.6	D/A Input	16
8.7	D/A State - Meters.....	16
8.8	D/A Reference.....	16
▶	Inputs and Outputs	
9	Analog Inputs / Outputs	
9.1	Line In.....	18
9.2	Line Out.....	19
10	Digital Inputs / Outputs	
10.1	AES / EBU.....	20
10.2	ADAT Optical	21
11	Word Clock	
11.1	Word Clock Input and Output.....	22
11.2	Technical Description and Background	23
11.3	Cables and Termination.....	24
▶	Technical Reference	
12	Technical Specifications	
12.1	Analog	26
12.2	Digital Inputs	27
12.3	Digital Outputs.....	28
12.4	Digital	28
12.5	Connector Pinouts.....	29
13	Technical Background	
13.1	Terminology	31
13.2	Lock and SyncCheck	32
13.3	Latency and Monitoring.....	33
13.4	DS – Double Speed	34
13.5	QS – Quad Speed.....	34
13.6	AES/EBU – SPDIF	35
13.7	Signal to Noise ratio in DS / QS Operation	36
13.8	SteadyClock	37
14	Block Diagram	38

Important Safety Instructions



ATTENTION! Do not open chassis – risk of electric shock

The unit has non-isolated live parts inside. No user serviceable parts inside. Refer service to qualified service personnel.



Mains

- The device must be earthed – never use it without proper grounding
- Do not use defective power cords
- Operation of the device is limited to the manual
- Use same type of fuse only



To reduce the risk of fire or electric shock do not expose this device to rain or moisture. Prevent moisture and water from entering the device. Never leave a pot with liquid on top of the device. Do not use this product near water, i. e. swimming pool, bathtub or wet basement. Danger of condensation inside – don't turn on before the device has reached room temperature.



Installation

Surface may become hot during operation – ensure sufficient ventilation. Avoid direct sun light and do not place it near other sources of heat, like radiators or stoves. When mounting in a rack, leave some space between this device and others for ventilation.



Unauthorized servicing/repair voids warranty. Only use accessories specified by the manufacturer.



Read the manual completely. It includes all information necessary to use and operate this device.



User's Guide



ADI-8 DS

▶ General

1. Introduction

RME's ADI-8 DS is an 8-channel high-end AD/DA converter with a truly unique feature set. The device combines excellent analog circuit design with the latest generation of outstanding low latency AD/DA converter chips. Along with its integrated SteadyClock, the ADI-8 DS offers AD and DA conversion of the highest quality.

When developing the ADI-8 DS we used all our experience, and also the experience of our customers, to create a unique, excellent and high-quality unit. Although the ADI-8 DS is built to highest reference standards, it still offers the typical, outstanding price/performance ratio known from RME. ADI-8 DS features will excite you – but even more the performance and smartness that it shows in solving any given task. Have fun!

2. Package Contents

Please check that your ADI-8 DS package contains each of the following:

- ADI-8 DS
- Power cord
- Manual
- 1 optical cable (TOSLINK), 2 m

3. Brief Description and Characteristics

The ADI-8 DS is an 8-channel hi-end AD and DA converter in reference quality. In a standard 19" box with 1 unit height the device offers numerous extraordinary features like Intelligent Clock Control (ICC), SyncCheck, SteadyClock, four hardware reference levels up to +24 dBu, AES/EBU and ADAT I/O, 192 kHz sample rate, and a digital patch mode.

- 8-channel AD converter, full symmetrical design, 119 dBA
- 8-channel DA converter, double balanced output, 120 dBA
- Low latency conversion: less than 12 samples delay
- 4 x AES/EBU I/O per D-sub, 8 channels @ 192 kHz
- 2 x ADAT I/O, 8 channels @ 96 kHz, 4 channels at 192 kHz
- Word clock input and output
- 2 x 8-channel level metering
- Noise suppression on power-on and power-off at the analog outputs
- Comprehensive digital patch mode for full interconnectivity

4. First Usage – Quick Start

4.1 Controls - Connectors - Displays

The front of the ADI-8 DS features 16 LED level meters, six select keys and 27 LEDs providing a detailed status display.

The analog input sensitivity can be changed in the area **A/D REFERENCE**.

In **A/D STATE** 8 level meters show the digital input level per channel.

The LEDs in **A/D OUTPUT** indicate which digital output currently carries the signal of the analog to digital conversion. With Patch Mode active the analog input signal is in some cases not available on the digital outputs ADAT and AES.

The comprehensive **PATCH MODE** turns the ADI-8 DS into a format converter, distributor and router, adding many advanced functions to the basic AD and DA conversion.

In the **CLOCK SECTION** the current clock reference and frequency multiplier is chosen.

The digital input signal of the DA-converters is chosen by pushing the **D/A INPUT** button.

In **D/A STATE** 8 level meters show the digital input level per channel.

D/A REFERENCE defines the analog reference level of the analog outputs. This level is reached at full scale of the DA-converters, thus matching the front panel level meter's level indication.

The rear panel of the ADI-8 DS has eight analog inputs, eight analog outputs, mains power, word clock I/O, and the digital inputs and outputs AES and ADAT.

ANALOG INPUTS: Eight balanced **Line inputs**, 1/4" TRS inputs and D-sub.

ANALOG OUTPUTS: Eight balanced **Line outputs**, 1/4" TRS outputs and D-sub.

AES I/O (25-pin D-sub): The D-sub connector provides four AES/EBU outputs and four AES/EBU inputs. The 25 pin D-sub connector is wired according to the widely spread Tascam standard (pinout see chapter 12.5). The AES I/Os are transformer-coupled. The high sensitivity type input accepts all common digital sources, even SPDIF.

ADAT I/O MAIN (TOSLINK): Standard ADAT optical port.

ADAT I/O AUX (TOSLINK): Transmits further channels at activated sample multiplexing.



WORD IN (BNC): A push switch allows to activate internal termination (75 Ohms).

WORD OUT (BNC): Standard word clock output.

IEC receptacle for power connection. The specially developed, internal hi-performance switch mode power supply lets the ADI-8 DS operate in the range of 100V to 240V AC. It is short-circuit-proof, has an integrated line-filter, is fully regulated against voltage fluctuations, and suppresses mains interference.

4.2 Quick Start Operation

After connection of all cables and power-on of the device, the configuration of the ADI-8 DS begins in the CLOCK section. Choose a clock source and a sample rate.

Connect the TRS-jacks or the D-sub connector with the analog signal source. Change the input sensitivity by pressing A/D REFERENCE until the input level is sufficient to avoid noisy operation. Try to achieve an optimum input level by adjusting the source itself. Raise the source's output level until the red Over LED flashes at the loudest parts of the signal, then reduce the level a bit until no more Overs are detected.

The analog line inputs of the ADI-8 DS can be accessed by using D-sub (for an optional XLR multicore) and 1/4" TRS jacks. Both are internally connected, so not operational at the same time. The electronic input stage is built in a servo balanced design which handles unbalanced (mono TS) and balanced (XLR, stereo TRS jacks) correctly, automatically adjusting the level reference.

On the DA-side just choose the desired digital input by pressing D/A INPUT. A coarse correction of the analog output level can be done by pressing the D/A REFERENCE button.

The ADI-8 DS stores all current settings and automatically activates them when the device is turned on.

5. Accessories

RME offers several optional components for the ADI-8 DS:

Part Number	Description
OK0050	Optical cable, Toslink, 0.5 m (1.7 ft)
OK0100	Optical cable, Toslink, 1 m (3.3 ft)
OK0200	Optical cable, Toslink, 2 m (6.6 ft)
OK0300	Optical cable, Toslink, 3 m (9.9 ft)
OK0500	Optical cable, Toslink, 5 m (16.4 ft)
OK1000	Optical cable, Toslink, 10 m (32.8 ft)
BO25MXLR4M4F1PRO	Digital Breakout Cable Pro, AES/EBU 25-pin D-sub to 4 x XLR male + 4 x XLR female, 1m (3.3 ft)
BO25MXLR4M4F3PRO	same, 3 m (9.9 ft)
BO25MXLR4M4F6PRO	same, 6 m (19.8 ft)
BO25M25M1PRO	Digital D-sub Cable Pro, AES/EBU, 25-pin D-sub to 25-pin D-sub, 1m (3.3 ft)
BO25M25M3PRO	same, 3m (9.9 ft)
BO25M25M6PRO	same, 6m (19.8 ft)
BO25MXLR8M3	Analog Breakout Cable, 25-pin D-sub to 8 x XLR male, 3 m (9.9 ft)
BO25MXLR8M6	same, 6 m (19.8 ft)
BO25MXLR8M10	same, 10 m (33 ft)
BO25MXLR8F3	Analog Breakout Cable 25-pin D-sub to 8 x XLR female, 3 m (9.9 ft)
BO25MXLR8F6	same, 6 m (19.8 ft)
BO25MXLR8F10	same, 10 m (33 ft)
BOB32	BOB-32, Universal breakout box, 19" 1 Unit height. The professional digital AES/EBU breakout solution

6. Warranty

Each individual ADI-8 DS undergoes comprehensive quality control and a complete test at IMM before shipping. The usage of high grade components should guarantee a long and trouble-free operation of the unit.

If you suspect that your product is faulty, please contact your local retailer.

Audio AG grants a limited manufacturer warranty of 6 months from the day of invoice showing the date of sale. The length of the warranty period is different per country. Please contact your local distributor for extended warranty information and service. Note that each country may have regional specific warranty implications.

In any case warranty does not cover damage caused by improper installation or maltreatment - replacement or repair in such cases can only be carried out at the owner's expense.

No warranty service is provided when the product is not returned to the local distributor in the region where the product had been originally shipped.

Audio AG does not accept claims for damages of any kind, especially consequential damage. Liability is limited to the value of the ADI-8 DS. The general terms of business drawn up by Audio AG apply at all times.

7. Appendix

RME news and further information can be found on our website:

<http://www.rme-audio.com>

Distributor: Audio AG, Am Pfanderling 60, D-85778 Haimhausen, Tel.: (49) 08133 / 91810

Manufacturer:

IMM Elektronik GmbH, Leipziger Strasse 32, D-09648 Mittweida

Trademarks

All trademarks and registered trademarks belong to their respective owners. RME, Hammerfall and DIGICheck are registered trademarks of RME Intelligent Audio Solutions. SyncAlign, SyncCheck, ZLM, SteadyClock, ADI-8 DS and Intelligent Clock Control (ICC) are trademarks of RME Intelligent Audio Solutions. Alesis and ADAT are registered trademarks of Alesis Corp. ADAT optical is a trademark of Alesis Corp. S/MUX is copyright Sonorus.

Copyright © Matthias Carstens, 10/2012. Version 1.0

All entries in this User's Guide have been thoroughly checked, however no guarantee for correctness can be given. RME cannot be held responsible for any misleading or incorrect information provided throughout this manual. Lending or copying any part or the complete manual or its contents as well as the software belonging to it is only possible with the written permission from RME. RME reserves the right to change specifications at any time without notice.

CE / FCC Compliance

CE

This device has been tested and found to comply with the limits of the European Council Directive on the approximation of the laws of the member states relating to electromagnetic compatibility according to RL2004/108/EG, and European Low Voltage Directive RL2006/95/EG.

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RoHS

This product has been soldered lead-free and fulfils the requirements of the RoHS directive.

ISO 9001

This product has been manufactured under ISO 9001 quality management. The manufacturer, IMM Elektronik GmbH, is also certified for ISO 14001 (Environment) and ISO 13485 (medical devices).

Note on Disposal

According to the guide line RL2002/96/EG (WEEE – Directive on Waste Electrical and Electronic Equipment), valid for all european countries, this product has to be recycled at the end of its lifetime.

In case a disposal of electronic waste is not possible, the recycling can also be done by IMM Elektronik GmbH, the manufacturer of the ADI-8 DS.

For this the device has to be sent **free to the door** to:

IMM Elektronik GmbH
Leipziger Straße 32
D-09648 Mittweida
Germany



Shipments not prepaid will be rejected and returned on the original sender's costs.



User's Guide




ADI-8 DS

▶ Usage and Operation

8. Front Panel Controls

8.1 A/D Reference

The analog input sensitivity of the AD-converters is referenced to digital full scale level (0 dBFS). The choices are: **+4.2 dBu** (-10 dBV compatible), **+13 dBu**, **+19 dBu** and **+24 dBu**. As the adaptation is performed in the analog domain, the ADI-8 DS achieves the highest possible values for Signal to Noise ratio and distortion in any setting.



8.2 A/D State - Meters

The 8 level meters of the **D/A STATE** show the digital value (dBFS) of the input level per channel. The red LED OVR is lit in half brightness 2 dB before full scale level (-2 dBFS), and full brightness at 0 dBFS.

8.3 A/D Output

The converted analog input signal is available at the ADAT and AES outputs simultaneously. When using Patch Mode, one or both of the digital outputs no longer carries the A/D signal, but a digital input signal (AES or ADAT) instead. The corresponding LED will be off then.

8.4 Patch Mode

Patch Mode controls the direct digital connection between all I/Os. 8 different modes are available. Each mode is clearly visualized by 6 LEDs. Pushing the button repeatedly steps through the following modes:



Format conversion

1. AES input to ADAT output
2. AES input to AES output
3. ADAT input to ADAT output
4. ADAT input to AES output

Double format conversion, parallel output mode

5. AES input to ADAT and AES output
6. ADAT input to ADAT and AES output

Bi-directional format conversion

7. AES input to ADAT output and ADAT input to AES output

Pass-through mode

8. AES input to AES output and AES input to AES output

Notes:

In modes 1 to 4 AD-conversion is still available on the AES or ADAT output.

In modes 5 to 8 AD-conversion is not available.

In single speed mode, the ADAT output signal is mirrored to the ADAT AUX output, so two ADAT devices can receive the same signal from the ADI-8 DS. This feature is available in any mode as long as the unit does not use sample rates higher than 48 kHz.

8.5 Clock Section

The source and frequency of the unit's clock is configured in the CLOCK section. The button CLOCK lets you step through the options external clock (Word, AES, ADAT) and internal clock, and sets the sample rate range for both an external and the internal clock.

WCK, AES, ADAT

Defines the corresponding input as clock reference. A missing or invalid clock source signal is indicated by flashing of the corresponding LED.

INT (Master Mode)

Activates the internal clock.



With a setting of INT (internal clock) it is mandatory that the clock rate of the sources is synchronous to the ADI-8 DS. Therefore the external device has to be synchronized to the ADI-8 DS word clock output or AES/ADAT output.

The ADI-8 DS thus has to be master, all devices connected to it must be slave. In order to avoid clicks and drop outs due to faulty or missing synchronicity, a special process called *SyncCheck* compares the incoming data and the ADI-8 DS internal clock. The SYNC state is indicated by a flashing (error) or constantly lit (OK) LED.


44.1, 48

Activates the internal clock at 44.1 kHz or 48 kHz.

DS, QS

With the DS LED additionally lit, the sample rate will be 88.2 or 96 kHz, with QS lit it will be 176.4 or 192 kHz.

A selection of DS and QS is also possible when using external clock (Slave). If the ADI-8 DS should operate at 192 kHz, but receives a synchronous word clock of 48 kHz, the button STATE allows to activate DS or QS mode. This way, AD-conversion and digital outputs are configured to operate in the frequency ranges Single Speed, Double Speed or Quad Speed.



Using AES as clock source the STATE key is disabled, as the sample rate is clearly given by the input signal. ADAT misses such information, therefore when ADAT is clock source the STATE has to be set manually.

Single Speed

All outputs carry a signal in the range of 32 kHz up to 48 kHz.

DS (Double Speed)

The AES outputs 1-8 carry a signal in the range of 64 kHz up to 96 kHz. ADAT stays at no higher than 48 kHz, with the data transmitted in the S/MUX format.

QS (Quad Speed)

The AES outputs 1-8 carry a signal in the range of 176.4 kHz up to 192 kHz. ADAT stays at no higher than 48 kHz, with the data transmitted in the S/MUX4 format. Therefore ADAT is limited to 4 channels (2 per optical output) in this mode.

8.6 D/A Input

The button **D/A Input** selects the signal source of the DA-converters. A currently active Patch Mode does not disable this function, the DA-conversion is always available.

Each input has its own SYNC LED. If a valid input signal is applied, SyncCheck is automatically active. SyncCheck takes the chosen clock (internal, external, etc.) as reference and compares it with the input clocks. Inputs which are not synchronous will be signalled by flashing of the corresponding SYNC LED.




8.7 D/A State - Meters

The 8 level meters of the **D/A STATE** show the digital input level per channel as digital value (dBFS). The yellow 0 dBFS LEDs become active already 2 dB before full scale level (-2 dBFS) with half brightness, and full brightness at 0 dBFS.

8.8 D/A Reference

The analog output level of the DA-converters is referenced to digital full scale level (0 dBFS). The choices are: **+4.2 dBu** (-10 dBV compatible), **+13 dBu**, **+19 dBu** and **+24 dBu**. As the adaptation is performed in the analog domain, the ADI-8 DS achieves the highest possible values for Signal to Noise ratio and distortion ratio in any setting.

When selecting +24 dBu the LEDs +19 dBu and +24 dBu are lit at the same time, indicating that the TRS jacks stay at +19 dBu while the D-sub connector outputs are operated at +24 dBu.



User's Guide



ADI-8 DS

► Inputs and Outputs


9. Analog Inputs / Outputs

9.1 Line In

The ADI-8 DS rear has 8 balanced Line inputs, provided by 1/4" TRS and a 25-pin D-sub connector. Both are internally connected, so can not be used at the same time. The electronic input stage is built in a servo balanced design which handles unbalanced (mono jacks) and balanced (XLR, stereo jacks) signals correctly, automatically adjusting the level reference.

When using unbalanced cables with XLR or TRS connectors be sure to connect pin 3 (- or ring) to 1 (ground). Otherwise noise may occur, caused by the unconnected negative input of the balanced input.

The 25-pin D-sub connector follows the pinout known from devices manufactured by Tascam (pinout see chapter 12.5). Your local dealer will supply analog breakout multicores D-sub to XLR in Tascam pinout in different lengths.



The ADI-8 DS uses a completely symmetrical signal path that guarantees an exceptional sound quality, outstanding low distortion and highest Signal to Noise ratio in all level settings.

One of the main issues when working with an AD-converter is to maintain the full dynamic range within the best operating level. Therefore the ADI-8 DS internally uses hi-quality electronic switches, which introduce no additional noise or distortion to the audio path. A/D REFERENCE allows for a perfect adaptation of all 8 channels to the most often used studio levels.

Each analog input has its own level meter, so every channel can be checked for input signal and overloads easily. The red LED OVR lights up 2 dB before full scale level (-2 dBFS) with half brightness, and full brightness at 0 dBFS.

The ADI-8 DS uses the following level references:

Reference	0 dBFS @	Headroom @ +4 dBu	Other RME devices
+24	+24 dBu	20 dB	-
+19	+19 dBu	15 dB	LoGain
+13	+13 dBu	9 dB	+4 dBu
+4.2	+4.2 dBu	12 dB at -10 dBV	-10 dBV


The setting +4.2 dBu equals -10 dBV with 12 to 15 dB headroom. Set to +24 dBu the ADI-8 DS is compatible to SMPTE (+24 dBu @ 0 dBFS, +4 dBu with 20 dB of headroom).


9.2 Line Out

The ADI-8 DS has 8 balanced Line outputs on the rear, provided by 1/4" TRS and a 25-pin D-sub connector. They have their own output drivers respectively and can therefore – in contrary to the inputs – be used simultaneously.

The electronic output stage of the TRS jacks is built in a servo-balanced design which handles unbalanced (mono plugs) and balanced (stereo plugs) correctly, automatically adjusting the level reference. The maximum output level is +21 dBu.

When selecting +24 dBu the LEDs +19 dBu and +24 dBu are lit at the same time, because the TRS jacks stay at the +19 setting, while the D-sub connector outputs are operated in the +24 setting.



 *The electronic output stage of the D-sub connector does not operate servo-balanced! When connecting unbalanced equipment, make sure pin 3 of the XLR output is not connected. A connection to ground can cause a higher THD value (higher distortion)!*

The 25-pin D-sub connector follows the pinout known from devices manufactured by Tascam (pinout see chapter 12.5). Your local dealer will supply analog breakout multicore D-sub to XLR in Tascam pinout in different lengths. The maximum output level at the D-sub connector is +27 dBu.

Each output channel has its own 7-segment level meter, so every channel can be checked for output signal and overloads easily. The level data are taken directly in front of the DA-converter. The yellow 0 dB LEDs light up 2 dB before full scale level (-2 dBFS) with half brightness, and full brightness at 0 dBFS.

To maintain an optimum level for devices connected to the analog outputs, the ADI-8 DS internally uses hi-quality electronic switches, which introduce no additional noise or distortion to the audio path. D/A REFERENCE allows for a perfect adaptation of all 8 channels to the most often used studio levels. The different output levels guarantee optimal conversion results, while still being compatible to any attached analog equipment.

The ADI-8 DS uses the following level references:

Reference	0 dBFS @	Headroom @ +4 dBu	Other RME devices
+24	+24 dBu	20 dB	-
+19	+19 dBu	15 dB	HiGain
+13	+13 dBu	9 dB	+4 dBu
+4.2	+4.2 dBu	12 dB at -10 dBV	-10 dBV

The setting +4.2 dBu equals -10 dBV with 12 to 15 dB headroom. Set to +24 dBu the ADI-8 DS is compatible to SMPTE (+24 dBu @ 0 dBFS, +4 dBu with 20 dB of headroom).

10. Digital Inputs / Outputs

10.1 AES/EBU

The four AES/EBU inputs and outputs are provided on the rear of the ADI-8 DS via a 25-pin D-sub connector with Tascam pinout (pinout see chapter 12.5). A digital breakout cable will provide 4 male and 4 female XLR connectors. Every input and output is transformer-balanced and galvanically isolated.

The inputs can be used in any combination, e. g. it is sufficient to connect an input signal only to input 3. In slave mode, this input is automatically being used as clock source. If more than one signal is present, the one furthest left is being used as clock source, i. e. the active input with the lowest number. Channel Status and Copy bit are ignored.

In standard operation the AES outputs carry the converted analog input signal. When activating Patch Mode the currently chosen digital input data is present at the outputs instead, see chapter 8.4.


The ADI-8 DS supports Single Wire only, in the range of 32 kHz up to 192 kHz: a total of 8 channels, 2 channels per AES wire. The effective sample frequency equals the clock on the AES wire. In case a conversion from/to Single, Double and Quad Wire is required, the RME ADI-192 DD, an 8-channel universal sample rate and format converter, is highly recommended.

Besides the audio data, digital signals in SPDIF or AES/EBU format contain a channel status coding, which is being used for transmitting further information. The output signal coding of the ADI-8 DS has been implemented according to AES3-1992 Amendment 4:


- 32 kHz, 44.1 kHz, 48 kHz, 64 kHz, 88.2 kHz, 96 kHz, 176.4 kHz, 192 kHz according to the current sample rate
- Audio use
- No Copyright, Copy permitted
- Format Professional
- Category General, Generation not indicated
- 2-Channel, No Emphasis
- Aux bits audio use, 24 bit
- Origin: RME

Emphasis

AES/EBU and SPDIF can contain Emphasis information. Audio signals with Emphasis have a strong high frequency boost and thus require high frequency attenuation on playback.

 *An Emphasis indication gets lost! This information is neither passed on to the ADAT output, nor to any of the AES outputs!*

Connecting devices with coaxial SPDIF ports to the ADI-8 DS inputs is accomplished by simple cable adapters XLR/RCA. To achieve this, pins 2 and 3 of an XLR plug are being connected to the two contacts of a Phono/RCA plug. The ground shield of the cable is only connected to pin 1 of the XLR plug.



The same is true for the outputs, but a male XLR connector is used then. Note that most consumer HiFi equipment with phono SPDIF inputs will only accept signals with Channel Status 'Consumer'! In such cases the above adapter cable will not work.

10.2 ADAT Optical

The ADI-8 DS provides two digital inputs and outputs in ADAT optical format. Using sample rates up to 48 kHz only the port labelled MAIN is relevant for operation. Higher sample rates than 48 kHz are realized by sample multiplexing. When using more than four channels at Double Speed or two channels at Quad Speed, the port labelled AUX has to be used as well.

The ADAT optical inputs of the ADI-8 DS use RME's unsurpassed Bitclock PLL, which prevents clicks and drop outs even in extreme varipitch operation, and guarantees a fast and low jitter lock to the digital input signal. A usual TOSLINK cable is sufficient for connection.

In Single Speed mode both outputs carry the same audio data. Therefore the output signal can be sent to two devices at the same time.

In standard operation the ADAT outputs carry the converted analog input signal. When activating Patch Mode the currently chosen digital input data is present at the outputs instead, see chapter 8.4.

The ADAT outputs can be used in parallel to the AES outputs at up to 192 kHz, but in Quad Speed mode only channels 1 to 4 will be available.

ADAT MAIN

Interface for the first or only device sending/receiving an ADAT signal. Carries the channels 1 to 8. In S/MUX mode (Double Speed), this port carries the channels 1 to 4. In S/MUX4 mode (Quad Speed) this port carries channels 1 and 2.

ADAT AUX

Additional port for a transmission of channels 5 to 8 in S/MUX mode, or 3 and 4 in S/MUX4 mode.

With signals encoded as S/MUX, the Clock Section (STATE) has to be switched into DS mode manually, depending on the current application. Each port carries the data of 4 channels only, for up to 8 channels MAIN *and* AUX have to be used.

With signals encoded as S/MUX4, the Clock Section (STATE) has to be switched into QS mode manually, depending on the current application. Each port carries the data of 2 channels only, for up to 4 channels MAIN *and* AUX have to be used.

11. Word Clock

11.1 Word Clock Input and Output

Input

The ADI-8 DS word clock input is active when WCK is chosen in the clock section. The signal at the BNC input can be Single, Double or Quad Speed, the ADI-8 DS automatically adapts to it. As soon as a valid signal is detected, the WCK LED is constantly lit, otherwise it is flashing.

Thanks to RME's *Signal Adaptation Circuit*, the word clock input still works correctly even with heavily mis-shaped, dc-prone, too small or overshoot-prone signals. Thanks to automatic signal centering, 300 mV (0.3 V) input level are sufficient in principle. An additional hysteresis reduces sensitivity to 1.0 V, so that over- and undershoots and high frequency disturbances don't cause a wrong trigger.

The word clock input is shipped as high impedance type (not terminated). A push switch allows to activate internal termination (75 Ohms). The switch is found on the back beside the BNC socket. Use a small pencil or similar and carefully push the blue switch so that it snaps into its lock position and the yellow LED lights up. Another push will release it again and de-activate the termination.



Output

The ADI-8 DS word clock output is constantly active, providing the current sample frequency as word clock signal. In master mode, the word clock will be fixed to 44.1 kHz or 48 kHz (DS x 2, QS x 4). In any other case the sample rate is identical to the one present at the currently chosen clock input. When the current word clock source fails, the last valid sample rate will be held automatically.

The word clock signal received by the ADI-8 DS can be distributed to other devices by using the word clock output. Due to its efficient jitter reduction the ADI-8 DS can clean up any clock signal, refresh it, and provide it as reference clock at the BNC output. With this the usual T-adapter can be avoided, and the ADI-8 DS operates as *Signal Refresher*. This kind of operation is highly recommended, because

- Input and output are phase-locked and in phase (0°) to each other
- SteadyClock removes nearly all jitter from the input signal
- the exceptional input (1 Vpp sensitivity instead of the usual 2.5 Vpp, dc cut, Signal Adaptation Circuit) plus SteadyClock guarantee a secure function also with most critical word clock signals.

Thanks to a low impedance, but short circuit proof output, the ADI-8 DS delivers 4 Vpp to 75 Ohms. For wrong termination with 2 x 75 Ohms (37.5 Ohms), there are still 3.3 Vpp at the output.

11.2 Operation and Technical Background

In the analog domain one can connect any device to another device, a synchronization is not necessary. Digital audio is different. It uses a clock, the sample frequency. The signal can only be processed and transmitted when all participating devices share the same clock. If not, the signal will suffer from wrong samples, distortion, crackle sounds and drop outs.

AES/EBU, SPDIF, ADAT and MADI are self-clocking, an additional word clock connection in principle isn't necessary. But when using more than one device simultaneously problems are likely to happen. For example any self-clocking will not work in a loop cabling, when there is no 'master' (main clock) inside the loop. Additionally the clock of all participating devices has to be synchronous. This is often impossible with devices limited to playback, for example CD players, as these have no SPDIF input, thus can't use the self clocking technique as clock reference.

In a digital studio synchronization is maintained by connecting all devices to a central sync source. For example the mixing desk works as master and sends a reference signal, the word clock, to all other devices. Of course this will only work as long as all other devices are equipped with a word clock or sync input, thus being able to work as slave (some professional CD players indeed have a word clock input). Then all devices get the same clock and will work in every possible combination with each other.



Remember that a digital system can only have one master! If the ADI-8 DS uses its internal clock, all other devices must be set to 'Slave' mode.

But word clock is not only the 'great problem solver', it also has some disadvantages. The word clock is based on a fraction of the really needed clock. For example SPDIF: 44.1 kHz word clock (a simple square wave signal) has to be multiplied by 256 inside the device using a special PLL (to about 11.2 MHz). This signal then replaces the one from the quartz crystal. Big disadvantage: because of the high multiplication factor the reconstructed clock will have great deviations called jitter. The jitter of a word clock is much higher as when using a quartz based clock.

The end of these problems should have been the so called Superclock, which uses 256 times the word clock frequency. This equals the internal quartz frequency, so no PLL for multiplying is needed and the clock can be used directly. But the Superclock proved to be much more critical than word clock. A square wave signal of 11 MHz distributed to several devices - this simply means to fight with high frequency technology. Reflections, cable quality, capacitive loads - at 44.1 kHz these factors may be ignored, at 11 MHz they are the end of the clock network. Additionally it was found that a PLL not only generates jitter, but also rejects disturbances. The slow PLL works like a filter for induced and modulated frequencies above several kHz. As the Superclock is used without any filtering such a kind of jitter and noise suppression is missing.

The actual end of these problems is offered by the **SteadyClock** technology of the ADI-8 DS. Combining the advantages of modern and fastest digital technology with analog filter techniques, re-gaining a low jitter clock signal of 22 MHz from a slow word clock of 44.1 kHz is no problem anymore. Additionally, jitter on the input signal is highly rejected, so that even in real world usage the re-gained clock signal is of highest quality.

11.3 Cabling and Termination

Word clock signals are usually distributed in the form of a network, split with BNC T-adapters and terminated with resistors. We recommend using off-the-shelf BNC cables to connect all devices, as this type of cable is used for most computer networks. Actually you will find all the necessary components (T-adapters, terminators, cables) in most electronics and computer stores. The latter usually carries 50 Ohm components. The 75 Ohm components used for word clock are part of video technology (RG59).

Ideally, the word clock signal is a 5 Volt square wave with the frequency of the sample rate, of which the harmonics go up to far above 500 kHz. To avoid voltage loss and reflections, both the cable itself and the terminating resistor at the end of the chain should have an impedance of 75 Ohm. If the voltage is too low, synchronization will fail. High frequency reflection effects can cause both jitter and sync failure.

Unfortunately there are still many devices on the market, even newer digital mixing consoles, which are supplied with a word clock output that can only be called unsatisfactory. If the output breaks down to 3 Volts when terminating with 75 Ohms, you have to take into account that a device, of which the input only works from 2.8 Volts and above, does not function correctly already after 3 meter cable length. So it is not astonishing that because of the higher voltage, word clock networks are in some cases more stable and reliable if cables are not terminated at all.

Ideally all outputs of word clock delivering devices are designed as low impedance types, but all word clock inputs as high impedance types, in order to not weaken the signal on the chain. But there are also negative examples, when the 75 Ohms are built into the device and cannot be switched off. In this case the network load is often 2×75 Ohms, and the user is forced to buy a special word clock distributor. Note that such a device is generally recommended for larger studios.

The ADI-8 DS word clock input can be high-impedance or terminated internally, ensuring maximum flexibility. If termination is necessary (e.g. because the ADI-8 DS is the last device in the chain), push the switch at the back (see chapter 11.1).

In case the ADI-8 DS resides within a chain of devices receiving word clock, plug a T-adapter into its BNC input jack, and the cable supplying the word clock signal to one end of the adapter. Connect the free end to the next device in the chain via a further BNC cable. The last device in the chain should be terminated using another T-adapter and a 75 Ohm resistor (available as short BNC plug). Of course devices with internal termination do not need T-adaptor and terminator plug.



Due to the outstanding SteadyClock technology of the ADI-8 DS, we recommend to not pass the input signal via T-adapter, but to use the ADI-8 DS word clock output instead. Thanks to SteadyClock, the input signal will both be freed from jitter and - in case of loss or drop out – be held at the last valid frequency.

User's Guide



ADI-8 DS

▶ **Technical Reference**

12. Technical Specifications

- Power supply: Internal, 100-240 V AC, 30 Watts
- Typical power consumption: 12 Watts
- Dimensions including rack ears (WxHxD): 483 x 44 x 242 mm (19" x 1.73" x 9.5")
- Dimensions without rack ears/handles (WxHxD): 436 x 44 x 235 mm (17.2" x 1.73" x 9.3")
- Weight: 2 kg (4.4 lbs)
- Temperature range: +5° up to +50° Celsius (41° F up to 122°F)
- Relative humidity: < 75%, non condensing

12.1 Analog

Line In 1-8, TRS/D-Sub

- Input: 6.3 mm TRS jack and D-sub 25-pin, servo-balanced
- Input impedance: 10 kOhm
- Input sensitivity switchable +24 dBu, +19 dBu, +13 dBu, +4.2 dBu @ 0 dBFS

AD-Conversion

- Resolution: 24 bit
- Signal to Noise ratio (SNR) @ +24 dBu, 44.1 kHz: 115.0 dB RMS unweighted, 119 dBA
- Signal to Noise ratio (SNR) @ +19 dBu: 114.9 dB RMS unweighted, 118 dBA
- Signal to Noise ratio (SNR) @ +13 dBu: 113.7 dB RMS unweighted, 117 dBA
- Signal to Noise ratio (SNR) @ +4.2 dBu: 109.8 dB RMS unweighted, 113 dBA
- Frequency response @ 44.1 kHz, -0.5 dB: 4 Hz – 20.8 kHz
- Frequency response @ 96 kHz, -0.5 dB: 4 Hz – 45.5 kHz
- Frequency response @ 192 kHz, -1 dB: 2 Hz – 90 kHz
- THD: < -110 dB, < 0.00032 %
- THD+N: < -104 dB, < 0.00063 %
- Channel separation: > 110 dB

DA-Conversion

- Resolution: 24 bit
- Signal to Noise ratio (SNR) @ +24 dBu, 44.1 kHz: 117,0 dB RMS unweighted, 120 dBA
- Signal to Noise ratio (SNR) @ +19 dBu: 117 dB RMS unweighted, 120 dBA
- Signal to Noise ratio (SNR) @ +13 dBu: 117 dB RMS unweighted, 120 dBA
- Signal to Noise ratio (SNR) @ +4.2 dBu: 114 dB RMS unweighted, 117 dBA
- Frequency response @ 44.1 kHz, -0.5 dB: 5 Hz – 22 kHz
- Frequency response @ 96 kHz, -0.5 dB: 5 Hz – 45.9 kHz
- Frequency response @ 192 kHz, -1 dB: 5 Hz - 90 kHz
- THD: < -104 dB, < 0.00063 %
- THD+N: < -102 dB, < 0.0008 %
- Channel separation: > 110 dB

Line Out 1-8, TRS

- Maximum output level: +21 dBu
- Output: 6.3 mm TRS jack, servo-balanced
- Output impedance: 75 Ohm
- Output level switchable +4.2 dBu, +13 dBu, +19 dBu @ 0 dBFS

Line Out 1-8, D-Sub

- Maximum output level: +27 dBu
- Output: D-sub 25-pin, electronically balanced
- Output impedance: 150 Ohm
- Output level switchable +4.2 dBu, +13 dBu, +19 dBu, +24 dBu @ 0 dBFS

12.2 Digital Inputs

AES/EBU

- 4 x 25-pin D-sub, transformer-balanced, galvanically isolated, according to AES3-1992
- High-sensitivity input stage ($< 0.3 V_{pp}$)
- SPDIF compatible (IEC 60958)
- Accepts Consumer and Professional format
- Lock Range: 27 kHz – 200 kHz
- Jitter when synced to input signal: $< 1 \text{ ns}$
- Jitter suppression: $> 30 \text{ dB}$ (2.4 kHz)

ADAT Optical

- 2 x TOSLINK, according to Alesis specification
- Standard: 8 channels 24 bit, up to 48 kHz
- S/MUX: 2 x 8 channels 24 bit / 48 kHz, equalling 8 channels 24 bit 96 kHz
- S/MUX4: 2 x 8 channels 24 bit / 48 kHz, equalling 4 channels 24 bit 192 kHz
- Bitclock PLL ensures perfect synchronization even in varispeed operation
- Lock range: 31.5 kHz – 54 kHz
- Jitter when synced to input signal: $< 1 \text{ ns}$
- Jitter suppression: $> 30 \text{ dB}$ (2.4 kHz)

Word Clock

- BNC, not terminated (10 kOhm)
- Switch for internal termination 75 Ohm
- Automatic Double/Quad Speed detection and internal conversion to Single Speed
- SteadyClock guarantees super low jitter synchronization even in varispeed operation
- Not affected by DC-offsets within the network
- Signal Adaptation Circuit: signal refresh through auto-center and hysteresis
- Overvoltage protection
- Level range: $1.0 V_{pp}$ – $5.6 V_{pp}$
- Lock Range: 27 kHz – 200 kHz
- Jitter when synced to input signal: $< 1 \text{ ns}$
- Jitter suppression: $> 30 \text{ dB}$ (2.4 kHz)

12.3 Digital Outputs

AES/EBU

- 4 x, transformer-balanced, galvanically isolated, according to AES3-1992
- Output voltage Professional 4.0 Vpp
- Format Professional according to AES3-1992 Amendment 4
- Single Wire: 4 x 2 channels 24 bit, up to 192 kHz

ADAT

- 2 x TOSLINK
- Standard: 8 channels 24 bit, up to 48 kHz
- S/MUX: 16 channels 24 bit / 48 kHz, equalling 8 channels 24 bit 96 kHz
- S/MUX4: 16 channels 24 bit / 48 kHz, equalling 4 channels 24 bit 192 kHz

Word Clock

- BNC
- Max. output voltage: 5 Vpp
- Output voltage @ 75 Ohm: 4.0 Vpp
- Impedance: 10 Ohm
- Frequency range: 27 kHz – 200 kHz

12.4 Digital

- Clocks: Internal, AES In, ADAT In, Word Clock In
- Low Jitter Design: < 1 ns in PLL mode, all inputs
- Internal clock: 800 ps Jitter, Random Spread Spectrum
- Jitter suppression of external clocks: > 30 dB (2.4 kHz)
- Effective clock jitter influence on AD-conversion: near zero
- PLL ensures zero dropout, even at more than 100 ns jitter
- Supported sample rates: 28 kHz up to 200 kHz

12.5 Connector Pinouts

D-Sub AES/EBU

The D-sub connector provides four AES inputs and outputs. The pinout uses the widely spread Tascam scheme.

Tascam:

Signal	In 1/2+	In 1/2-	In 3/4+	In 3/4-	In 5/6+	In 5/6-	In 7/8+	In 7/8-
D-Sub	24	12	10	23	21	9	7	20

Signal	Out 1/2+	Out 1/2-	Out 3/4+	Out 3/4-	Out 5/6+	Out 5/6-	Out 7/8+	Out 7/8-
D-Sub	18	6	4	17	15	3	1	14

GND is connected to pins 2, 5, 8, 11, 16, 19, 22, 25. Pin 13 is not connected.

The Yamaha pinout is quite popular as well. When building a D-sub to D-sub adapter or connection cable, please make sure that the connectors are clearly labelled with *Tascam* and *Yamaha*. The cable can only be used when the Tascam side is connected to a Tascam connector, and the Yamaha side is connected to a Yamaha connector.

Yamaha:

Signal	In 1/2+	In 1/2-	In 3/4+	In 3/4-	In 5/6+	In 5/6-	In 7/8+	In 7/8-
D-Sub	1	14	2	15	3	16	4	17

Signal	Out 1/2+	Out 1/2-	Out 3/4+	Out 3/4-	Out 5/6+	Out 5/6-	Out 7/8+	Out 7/8-
D-Sub	5	18	6	19	7	20	8	21

GND is connected to pins 9, 10, 11, 12, 13, 22, 23, 24, 25.

The same is true for a direct adapter cable Tascam D-sub to Euphonix D-sub.

Euphonix:

Signal	In 1/2+	In 1/2-	In 3/4+	In 3/4-	In 5/6+	In 5/6-	In 7/8+	In 7/8-
D-Sub	15	2	4	16	18	5	7	19

Signal	Out 1/2+	Out 1/2-	Out 3/4+	Out 3/4-	Out 5/6+	Out 5/6-	Out 7/8+	Out 7/8-
D-Sub	21	8	10	22	24	11	13	25

GND is connected to pins 3, 6, 9, 12, 14, 17, 20, 23. Pin 1 is not connected.

D-Sub Analog Inputs / Outputs

The 25 pin D-sub connectors of analog input and output are wired according to the Tascam scheme, as shown in this table:

Channel	1+	1-	2+	2-	3+	3-	4+	4-	5+	5-	6+	6-	7+	7-	8+	8-
D-sub	24	12	10	23	21	9	7	20	18	6	4	17	15	3	1	14

GND is connected to pins 2, 5, 8, 11, 16, 19, 22, 25. Pin 13 is unconnected.

The servo balanced input circuitry allows to use unbalanced connections with no loss in level. For this to work, pins 3 (-) and 1 (GND) have to be connected.

The output circuitry does not operate in a servo-balanced way. When connecting unbalanced devices make sure that pin 3 (-) stays unconnected.

TRS jacks analog inputs / outputs

The stereo ¼" TRS jacks of the analog inputs are wired according to international standards:

Tip = + (hot)
Ring = - (cold)
Sleeve = GND

The servo-balanced circuitry allows to use monaural TS jacks (unbalanced) with no loss in level. This is the same as when using a TRS-jack with ring connected to ground.

13. Technical Background

13.1 Terminology

Single Speed

Sample rate range originally used in Digital Audio. Typical applications are 32 kHz (digital radio broadcast), 44.1 kHz (CD), and 48 kHz (DAT).

Double Speed

Doubles the original sample rate range, in order to achieve higher audio quality and improved audio processing. 64 kHz is practically never used, 88.2 kHz is quite rare in spite of certain advantages. 96 kHz is a common format. Sometimes called **Double Fast**.

Quad Speed

Controversially discussed way of ensuring hi-end audio quality and processing by quadrupling the sample frequency. 128 kHz is non-existent, 176.4 kHz is rare, if at all then 192 kHz is used, e.g. for DVD Audio.

Single Wire

Standard audio data transfer, where the audio signal's sample rate is equal to the rate of the digital signal. Used from 32 to 192 kHz. Sometimes called **Single Wide**.

Double Wire

Before 1998 there were no receiver/transmitter circuits available that could receive or transmit more than 48 kHz. Higher sample rates were transferred by splitting odd and even bits across the L/R channels of a single AES connection. This provides for twice the data rate, and hence twice the sample rate. A stereo signal subsequently requires two AES/EBU ports.

The Double Wire method is an industry standard today, however it has a number of different names, like **Dual AES**, **Double Wide**, **Dual Line** and **Wide Wire**. The AES3 specification uses the uncommon term *Single channel double sampling frequency mode*. When used with the ADAT format, the term S/MUX is commonly used.

Double Wire not only works with Single Speed signals, but also with Double Speed. As an example, Pro Tools HD, whose AES receiver/transmitter only work up to 96 kHz, uses Double Wire to transmit 192 kHz. Four channels of 96 kHz turn into two channels of 192 kHz.

Quad Wire

Similar to Double Wire, with samples of one channel spread across four channels. This way single speed devices can transmit up to 192 kHz, but need two AES/EBU ports to transmit one channel. Also called **Quad AES**.

S/MUX

Since the ADAT hardware interface is limited to Single Speed, the Double Wire method is used for sample rates up to 96 kHz, but usually referred to as S/MUX (Sample Multiplexing). An ADAT port supports four channels this way.

S/MUX4

The Quad Wire method realizes the transmission of two channels at up to 192 kHz via ADAT. The method is referred to as S/MUX4.

Note: All conversions of the described methods are lossless. The existing samples are just spread or re-united between the channels.

13.2 Lock and SyncCheck

Digital signals consist of a carrier and the data. If a digital signal is applied to an input, the receiver has to synchronize to the carrier clock in order to read the data correctly. To achieve this, the receiver uses a PLL (Phase Locked Loop). As soon as the receiver meets the exact frequency of the incoming signal, it is locked. This **Lock** state remains even with small changes of the frequency, because the PLL tracks the receiver's frequency.

If an AES signal is applied to the ADI-8 DS, the corresponding LED starts flashing. The unit indicates LOCK, i. e. a valid input signal (in case the signal is in sync, the LED is constantly lit, see below).

Unfortunately, LOCK does not necessarily mean that the received signal is correct with respect to the clock which processes the read out of the embedded data. Example [1]: The ADI-8 DS is set to 44.1 kHz internal clock (clock mode master), and a mixing desk with AES output is connected to the DS input. The AES LED will start flashing immediately, because the mixing desk's sample rate is generated internally, and thus slightly higher or lower than the ADI-8 DS' internal sample rate. Result: When reading out the data, there will frequently be read errors that cause clicks and drop outs.

Also when using multiple inputs, a simple LOCK is not sufficient. The above described problem can be solved elegantly by setting the ADI-8 DS from internal clock to AES (its internal clock will then be the clock delivered by the mixing desk). But in case another asynchronous device is connected, there will again be a slight difference in the sample rate, and therefore clicks and drop outs.

In order to display those problems optically at the device, the ADI-8 DS includes **SyncCheck**. It checks all clocks used for synchronicity. If they are not synchronous to each other (i. e. absolutely identical), the LED of the asynchronous input flashes. In case they are synchronous the LED stays dark, only the LED of the current clock source will be constantly lit. In example 1 it would have been obvious that the AES LED starts flashing after connecting the mixing desk.

In practice, SyncCheck allows for a quick overview of the correct configuration of all digital devices. This way one of the most difficult and error-prone topics of the digital studio world finally becomes easy to handle.

13.3 Latency and Monitoring

The term **Zero Latency Monitoring** has been introduced by RME in 1998 for the DIGI96 series and describes the ability to pass-through the computer's input signal at the interface directly to the output. Since then, the idea behind has become one of the most important features of modern hard disk recording. In the year 2000, RME published two ground-breaking Tech Infos on the topics *Low Latency Background*, which are still up-to-date: *Monitoring, ZLM and ASIO*, and *Buffer and Latency Jitter*, found on the RME website.

How much Zero is Zero?

From a technical view there is no zero. Even the analog pass-through is subject to phase errors, equalling a delay between input and output. However, delays below certain values can subjectively be claimed to be a zero-latency. This applies to analog routing and mixing, and in our opinion also to RME's Zero Latency Monitoring. RME's digital receiver's buffer and the output via the transmitter cause a typical delay of 3 samples. At 44.1 kHz this equals about 68 μ s (0.000068 s), at 192 kHz only 15 μ s.

Oversampling

While the delays of digital interfaces can be disregarded altogether, the analog inputs and outputs do cause a significant delay. Modern converter chips operate with 64 or 128 times oversampling plus digital filtering, in order to move the error-prone analog filters away from the audible frequency range as far as possible. This typically generates a delay of about 40 samples, equalling one millisecond. A playback and re-record of the same signal via DA and AD (loop-back) then causes an offset of the newly recorded track of about 2 ms.

Low Latency!

The ADI-8 DS uses the latest top AD- and DA-converters with special low latency filters, offering exceptional Signal to Noise and distortion figures and a super-fast conversion. A delay of down to 5 samples had been unavailable a few years back. The exact delays caused by the AD- and DA-conversion of the ADI-8 DS Mk III are:

Sample frequency kHz	44.1	48	88.2	96	176.4	192
AD (12.6 x 1/fs) ms	0.28	0.26				
AD (12.6 x 1/fs) ms			0.14	0.13		
AD (9.8 x 1/fs) ms					0.055	0.05
DA (10 x 1/fs) ms	0.22	0.2				
DA (5 x 1/fs) ms			0.056	0.052		
DA (5 x 1/fs) ms					0.028	0.026

These values are less than a quarter of those available from even much more expensive devices. They represent an important step in further reducing the latency in the computer-based recording studio. At Double Speed and Quad Speed the added latency can simply be ignored. In short: the ADI-8 DS turns 'analog digital monitoring' into real analog-style monitoring.

13.4 DS - Double Speed

When activating the *Double Speed* mode the ADI-8 DS operates at double sample rate. The internal clock 44.1 kHz turns to 88.2 kHz, 48 kHz to 96 kHz. The internal resolution is still 24 bit.

Sample rates above 48 kHz were not always taken for granted, and are still not widely used because of the CD format (44.1 kHz) dominating everything. Before 1998 there were no receiver/transmitter circuits available that could receive or transmit more than 48 kHz. Therefore a work-around was used: instead of two channels, one AES line only carries one channel, where odd and even samples are being distributed to the former left and right channels. By this, you get the double amount of data, i. e. also double sample rate. Of course in order to transmit a stereo signal two AES/EBU ports are necessary then.

This transmission mode is called *Double Wire* in the professional studio world, and is also known as *S/MUX (Sample Multiplexing)* in connection with the ADAT format.

Not before February 1998, Crystal shipped the first 'single wire' receiver/transmitters that could also work with double sample rate. It was then possible to transmit two channels of 96 kHz data via one AES/EBU port.

But *Double Wire* is still present today. On one hand, there are still many devices which can't handle more than 48 kHz, e. g. digital tape recorders. But also other common interfaces like ADAT or TDIF are still using this technique.

Because the ADAT interface does not allow for sampling frequencies above 48 kHz (a limitation of the interface hardware), the ADI-8 DS automatically uses *Sample Multiplexing* in DS mode. One channel's data is distributed to two channels according to the following table:

Analog In	1	2	3	4	5	6	7	8
DS Signal Port	1/2 ADAT1	3/4 ADAT1	5/6 ADAT1	7/8 ADAT1	1/2 ADAT2	3/4 ADAT2	5/6 ADAT2	7/8 ADAT2

As the transmission of double rate signals is done at standard sample rate (Single Speed), the ADAT outputs still deliver 44.1 kHz or 48 kHz.

13.5 QS – Quad Speed

Due to the small number of available devices that use sample rates up to 192 kHz, but even more due to a missing real world application (CD...), Quad Speed has had no broad success so far. An implementation of the ADAT format as double S/MUX (S/MUX4) results in only two channels per optical output. Therefore in Quad Speed mode the ADI-8 DS is limited to 4 channels at the ADAT outputs.

The AES outputs provide 192 kHz as Single Wire only, thus transmitting all 8 channels without limitations.

13.6 AES/EBU - SPDIF

The most important electrical properties of 'AES' and 'SPDIF' can be seen in the table below. AES/EBU is the professional balanced connection using XLR plugs. The standard is being set by the *Audio Engineering Society* based on the AES3-1992. For the 'home user', SONY and Philips have omitted the balanced connection and use either Phono plugs or optical cables (TOSLINK). The format called S/P-DIF (SONY/Philips Digital Interface) is described by IEC 60958.

Type	AES3-1992	IEC 60958
Connection	XLR	RCA / Optical
Mode	Balanced	Unbalanced
Impedance	110 Ohm	75 Ohm
Level	0.2 V up to 5 Vpp	0.2 V up to 0.5 Vpp
Clock accuracy	not specified	I: ± 50 ppm II: 0.1% III: Variable Pitch
Jitter	< 0.025 UI (4.4 ns @ 44.1 kHz)	not specified

Besides the electrical differences, both formats also have a slightly different setup. The two formats are compatible in principle, because the audio information is stored in the same place in the data stream. However, there are blocks of additional information, which are different for both standards. In the table, the meaning of the first byte (#0) is shown for both formats. The first bit already determines whether the following bits should be read as Professional or Consumer information.

Byte	Mode	Bit 0	1	2	3	4	5	6	7
0	Pro	P/C	Audio?	Emphasis			Locked	Sample Freq.	
0	Con	P/C	Audio?	Copy	Emphasis			Mode	

It becomes obvious that the meaning of the following bits differs quite substantially between the two formats. If a device like a common DAT recorder only has an SPDIF input, it usually understands only this format. In most cases, it will switch off when being fed Professional-coded data. The table shows that a Professional-coded signal would lead to malfunctions for copy prohibition and emphasis, if being read as Consumer-coded data.

Nowadays many devices with SPDIF input can handle Professional subcode. Devices with AES3 input almost always accept Consumer SPDIF (passive cable adapter required).

13.7 Signal to Noise Ratio in DS- / QS-Operation


The outstanding signal to noise ratio of the ADI-8 DS AD-converters can be verified even without expensive test equipment, by using record level meters of various software. But when activating the DS and QS mode, the displayed noise level will rise from -115 dBFS to -106 dBFS at 96 kHz, and -79 dBFS at 192 kHz. This is not a failure. The software measures the noise of the whole frequency range, at 96 kHz from 0 Hz to 48 kHz (RMS unweighted), at 192 kHz from 0 Hz to 96 kHz.

When limiting the measurement range from 20 Hz to 20 kHz (so called audio bandpass) the value would be -114 dB again. This can be verified with RME's *DIGICheck*. The function **Bit Statistic & Noise** measures the noise floor by *Limited Bandwidth*, ignoring DC and ultrasound.

Subframe	MSB	Audio Data	LSB	AUX	CUV	RMS LB [dB+3]	RMS [dBA+3]	DC [dB]
1 - Left	████████	████████	████████	████████	000	-114.0	-117.0	-164.7
2 - Right	████████	████████	████████	████████	000	-114.0	-117.1	-170.0
Bits	4	8	12	16	20	24	20Hz ... 20kHz	A-weighting

Press F1 for help. SR 192kHz

The reason for this behaviour is the noise shaping technology of the analog to digital converters. They move all noise and distortion to the in-audible higher frequency range, above 30 kHz. Therefore the noise is slightly increased in the ultrasound area. High-frequency noise has a high energy. Add the quadrupled bandwidth, and a wideband measurement will show a significant drop in SNR, while the human ear will notice absolutely no change in the audible noise floor.



As can be seen in the above picture, the noise floor stays at a remarkably low level even outside the hearing range. At sample rates of up to 96 kHz the noise shaping happens completely outside of the transmission range.


13.8 SteadyClock

The SteadyClock technology of the ADI-8 DS guarantees an excellent performance in all clock modes. Its highly efficient jitter suppression refreshes and cleans up any clock signal, and provides it as reference clock at the word clock output.

Usually a clock section consists of an analog PLL for external synchronization and several quartz oscillators for internal synchronization. SteadyClock requires one quartz only, using a frequency not equalling digital audio. Latest circuit designs like hi-speed digital synthesizer, digital PLL, 100 MHz sample rate and analog filtering allow RME to realize a completely newly developed clock technology, right within the FPGA at lowest costs. The clock's performance exceeds even professional expectations. Despite its remarkable features, SteadyClock reacts quite fast compared to other techniques. It locks in fractions of a second to the input signal, follows even extreme varipitch changes with phase accuracy, and locks directly within a range of 28 kHz up to 200 kHz.


SteadyClock has originally been developed to gain a stable and clean clock from the heavily jittery MADI data signal. The embedded MADI clock suffers from about 80 ns jitter, caused by the time resolution of 125 MHz within the format. Common jitter values for other devices are 5 ns, while a good clock will have less than 2 ns.

The picture to the right shows the MADI input signal with 80 ns of jitter (top graph, yellow). Thanks to SteadyClock this signal turns into a clock with less than 2 ns jitter (lower graph, blue).



Using the input sources of the ADI-8 DS, word clock, ADAT and AES/EBU, you'll most probably never experience such high jitter values. But SteadyClock is not only ready for these, it would also handle them just on the fly.

The screenshot to the right shows an extremely jittery word clock signal of about 50 ns jitter (top graph, yellow). Again SteadyClock provides an extreme clean-up. The filtered clock shows less than 2 ns jitter (lower graph, blue).



The cleaned and jitter-free signal can be used as reference clock for any application, without any problem. The signal processed by SteadyClock is of course not only used internally, but also available at the ADI-8 DS' word clock output. It is also used to clock the digital outputs ADAT and AES/EBU.

14. Block Diagram

